

Combi-Rinse

Premium Combination Oven Rinse/Neutralizer

Product Number 4700

Description

A unique concentrated rinse additive for use through the integral cleaning system on combination ovens. Dosed automatically following the oven's cleaning program, Combi-Rinse neutralizes any alkaline detergent residues and ensures an effective rinse process. Will reduce water spot marking and help to control water scale if used regularly. Suitable for use in both atmospheric and non-atmospheric (pressurized) ovens.

Directions

Combi-Rinse must only be used via the integrated dosing system on combination ovens. Concentration can be adjusted via the oven control panel to achieve a suitable level of rinse effectiveness. Typical dilution rate is between 1 to 2 ounces per gallon of rinse solution. Care should always be taken when changing containers. Always ensure that chemical containers are placed in a safe location. Only use in combination ovens with an appropriate backflow preventer.

Technical Data

Color	Clear, Teal	Phosphated	No
Scent	N/A	Viscosity	Low
pH (1% solution)	2.3 – 3.3	Density	8.7 lbs./gallon

Product Category: Warewash/Mechanical Washing

DOT Shipping Name: Compound, Cleaning, Liquid



WARNING

HAZARDS: Causes mild skin irritation. Causes serious eye irritation.

PRECAUTIONS: Wash hands thoroughly after handling. Wear eye protection.

RESPONSE/FIRST AID: Have the product container or label with you when calling poison control center or physician. **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Call a poison control center or physician for treatment advice. If eye irritation persists, get medical advice/attention. **IF SWALLOWED:** Rinse mouth. Do NOT induce vomiting. Call a POISON CENTER or physician for treatment advice. **IF ON SKIN (or hair):** Remove immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. **IF INHALED:** Remove victim to fresh air and keep at rest in a position comfortable for breathing.

STORAGE & DISPOSAL: No GHS phrases apply. Refer to the SDS for additional information.